Four Quadrant Metering

Steve Hudson, PE

VP Of Hardware Engineering

10737 Lexington Drive
Knoxville, TN 37932

Phone: (865) 966-5856

www.powermetrix.com

Focus of this Presentation

- Review of Watts, VAR, and VA
- Overview of Four Quadrant Metering
- Vector Diagrams in Four Quadrants
- How do you meter four quadrants?
- Examples of sites using four quadrant metering
- Verification of four quadrant sites

POWERMETRIX

Watt, VAR, and VA

Watt - useful power that does real work at the load – light a bulb or turn a motor

VAR – non-useful power that is required to drive the inductance or capacitance of a power line

VA – the total power in the system; the vector sum of Watts and VARs

POWERMETRIX

Watt, VAR, and VA

POWERMETRIX

Where do VARs come from?



Inductance in the power transmission line lower power factor and increases VARs!

POWERMETRIX

Four Quadrant Metering

Quadrant	Power Factor	Watts	VARs
1	Lag	Delivered (+)	Delivered (+)
2	Lead	Received (-)	Delivered (+)
3	Lag	Delivered (+)	Received (-)
4	Lead	Received (-)	Received (-)

POWERMETRIX

Four Quadrant Metering



Delivered power goes from the utility to the customer
Received power goes from the customer to the utility

POWERMETRIX

IMPORTANT!

The four quadrants shown in the last slide are NOT the same as a typical vector diagram!





POWERMETRIX

Quadrant 1





- Most common quadrant
- Inductive load

POWERMETRIX

Quadrant 2





Renewable sites with a capacitive load



POWERMETRIX

Quadrant 3





Renewable sites with a inductive load

POWERMETRIX

Quadrant 4





Light load on a standard site with a capacitor bank



POWERMETRIX

How are 4 quadrants metered?

- Old approach – use two meters
- Mechanical meter with detents
- Possible problems with VARhr meters
- Solid state meters can perform true 4 quadrant metering
- Solid state metering can also be used for net energy metering

POWERMETRIX

Net Energy Metering

- Net metering allows a customer to be credited or paid for excess energy generated from renewable resources
- In some cases, net energy is credited at the full energy rate
- States limit the amount of excess energy that can be credited to the customer

POWERMETRIX

Net Energy Example

- Customer consumes 500kWh from the utility at $0.10/kWh

  500kWh * $0.10/kWh = $50 due to utility

- Customer puts back 100kWh to the utility at $0.05/kWh

  100kWh * $0.05/kWh = $5 due to customer

  Net bill = $50 - $5 = $45 due to utility

POWERMETRIX

Renewable Metering

- Renewable sites can generate excess energy that can be put back on the grid
- This requires a means to measure power *received* back on to the electrical grid
- Originally, two meters were used – one for power delivered to the customer, and one for received power to the utility
- Modern meters can measure energy flow in both directions – 4 quadrant metering

POWERMETRIX

What is a renewable site?

A renewable site can produce its own energy using a resource that is naturally replenished.

POWERMETRIX

Renewable Site Statistics



POWERMETRIX

Renewable Site Statistics



POWERMETRIX

Renewable Site Statistics

- Renewable energy accounted for 10% of total power consumption in the US in 2016

- Solar and wind are the largest growing segments in the US and represent the majority of new renewable metering installations. Both segments should double their output in the next 5 years.

Source: www.eia.gov

POWERMETRIX

Case Study #1
East Knox Solar Array

1MW Solar Farm in Knoxville, TN
4608 Panels - Built 2010

POWERMETRIX

East Knox Solar Array

Four DC-AC Inverters
8.4kV Transformer

POWERMETRIX

East Knox Solar Array

- Local utility monitors energy with one bi-directional form 9S meter
- 200:5 CT’s
- 70:1 PT’s

POWERMETRIX

East Knox Solar Array



- Current vectors are LEADING
- Meter is setup so that positive energy flow is from the solar array to the utility

POWERMETRIX

East Knox Solar Array



- Power outputs are well filtered
- Harmonics are >70th harmonic
- Meter should have no problems

POWERMETRIX

East Knox Solar Array



- Customer Load Meter Test has excellent results
- Note NEGATIVE VARh due to leading current

POWERMETRIX

East Knox Solar Array

- Overhead CT's are testing using a high voltage current probe to measure primary current
- Pay attention to the polarity of the CT
- Secondary current is available at the meter test switch

POWERMETRIX

East Knox Solar Array



POWERMETRIX

East Knox Solar Array



Direct Burden Measurement gives the EXACT burden on the secondary

POWERMETRIX

Case Study #2
Gila River PV Power Plant

87kW Solar Farm at Hu Hu Kam Hospital
Sacaton, AZ

POWERMETRIX

Gila River PV Power Plant



- The vector diagram for a renewable site may have current vectors 180° out when the site is generating power.
- Whr, VARhr, and PF may also be negative when generating power.

POWERMETRIX

Gila River PV Power Plant



Voltage and Current Harmonics

V THD = 2%

I THD = 50 to 60%

Square wave current due to inverter

POWERMETRIX

Case Study #3
U-Haul – Kingman, AZ

POWERMETRIX

U-Haul – Kingman, AZ

Meter Vector Diagram



- Single Phase – 3 wire Form 4S meter
- Power was being put back on the grid - Negative Watts
- Meter registration was -100.9%

Power Data

Power Pair	Wh	VAh	VARh
Vab-Ia	-1.7247	1.7277	-0.0092
Vab-Ib	-1.2472	1.2585	0.1411
Sys	-2.9719	2.9749	0.1319

POWERMETRIX

U-Haul – Kingman, AZ



- Single Phase – 3 wire Form 4S meter
- Power was being delivered to the customer - Positive Watts
- Meter registration was +100.15%

Power Data

Power Pair	Wh	VAh	VARh
Vab-Ia	1.6058	1.6137	-0.1320
Vab-Ib	1.3897	1.3958	-0.1009
Sys	2.9954	3.0045	-0.2330

POWERMETRIX

U-Haul – Kingman, AZ



Voltage THD < 3%
Current THD < 17%
Mostly odd harmonics due to inverter

POWERMETRIX

Renewable Site Verification

- Renewable sites should be tested for energy flow in both directions.
- This will require the use of a load box.
- If the site is not generating power, a phantom load test will be required.
- Always check your CTs and PTs – The meter is only as good as the information it receives from the ITs!

POWERMETRIX

Summary

- Wind and solar sites will produce many new metering sites over the next 6 to 20 years
- Four quadrant metering is required for bidirectional energy sites
- Check energy flow in both directions

POWERMETRIX

Questions? Comments?

Want a copy of this presentation?

Go to

https://www.powermetrix.com/presentations/

Thank you for your time!

POWERMETRIX